

W312 Firmware Upgrade Instructions


Step 1: Connect PC to the W312 via WiFi

Step 2: Login the 10.10.10.1

Enter the user name, password

The user name : **admin**

The password : **admin**




The screenshot shows a web browser window with the address bar containing "10.10.0.1/cgi-bin/luci". The page title is "AP - LuCI". The main content area has a dark header with "AP" in white. Below the header, the text "Authorization Required" is displayed in blue, followed by the instruction "Please enter your username and password." There are two input fields: "Username" with the value "admin" and "Password" with masked characters ".....". Below the input fields are two buttons: "Login" (with a green arrow icon) and "Reset" (with a red 'X' icon). At the bottom of the page, the version information "W312-V1R3 B1607D05 (cf7e69d3) r49397" is shown.

Step 1:

a.Choose "System"

b.Choose "Backup/Flash firmware"




Step 2:

Click "Choose File" ,choose the new upgrade file on PC

Then click "Flash image"

Notice: DO NOT Click "Keep settings"



Step 3:

Click "Proceed" , AP automatically restart and firmware upgrading.

Waiting 3mints connected AP again. Check the version number to make sure the upgrade successful.

NOTICE : DO NOT CUT OFF THE POWER DURING THE UPGRADING. Otherwise, it will cause device failure.

